GV | Faux Leather



CLEANING CODE

CFC: Coated Fabrics Cleaning - When a spill/stain occurs wipe immediately with a clean dry cloth. Carefully remove the majority of the stain then follow the steps below.

Soap & Water - Remove ordinary dirt and smudges with a mild soap and water solution using a soft cloth or towel. Rinse with fresh water and wipe dry.

Non-abrasive Cleaners - If residue remains, use a straight application of the following cleaners: Fantastik or 409 and gently clean with a soft cloth. Rinse with fresh water and wipe dry.

Isopropyl Alcohol - More stubborn stains may be eliminated using a cotton cloth soaked in 70-91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft brush is recommended to clean valleys and crevices. Rinse with fresh water and wipe dry.

BC: Bleach Cleanable - 1 parts bleach, 9 parts water = 10% bleach, 90% water solution. Do not clean / disinfect fabric for longer than 10 minutes using the 10% bleach solution. Always rinse promptly with clean water after applying the bleach solution. Failure to do so will void any and all warranties.

Please note: If specific cleaners are not listed, then the pattern has not been tested for cleaning solution compatibility.

DISINFECTANTS AND CLEANERS

ACCEL PREVENTION CONCENTRATE – Approved - Slight Effect ACCEL TB – Approved - No Effect BIREX SE DISINFECTANT – Approved - Slight Effect CAVIWIPES – Approved - Slight Effect CITRACE GERMACIDE – Approved - Slight Effect CLOROX DISINFECTING WIPE – Approved - No Effect CLOROX HEALTHCARE BLEACH GERMICIDAL WIPE – Approved - Slight Effect CLOROX HEALTHCARE EZ-KILL QUAT ALCOHOL CLEANER DIS... – Approved - Slight Effect

500 S. KITLEY AVE., INDIANAPOLIS, IN 46219 TOLL FREE: 800.428.4415 T: 317.267.2626 F: 317-267-2629

MAYERFABRICS

CLOROX HYDROGEN PEROXIDE CLEANER DISINFECTANT SPRA... – Approved - No Effect CLOROX HEALTHCARE HYDROGEN PEROXIDE CLEANER DISINF... – Approved - Slight Effect ECOLAB NEUTRAL DISINFECTANT CLEANER - Approved - No Effect FADE-A-DYNE II - Approved - Slight Effect FANTASTIK ALL PURPOSE CLEANER - Approved - No Effect FORMULA 409 ALL PURPOSE CLEANER - Approved - Slight Effect **GREEN WORKS ALL PURPOSE CLEANER – Approved - No Effect ISOPROPYL ALCOHOL – Approved - No Effect** LYSOL FOAMING - Approved - No Effect LYSOL SPRAY DISINFECTANT - Approved - No Effect OASIS 146 MULTI-QUAT SANITIZER - Approved - No Effect OASIS 144 QUAT SANITIZER - Approved - No Effect OPTIM 33 TB DISINFECTANT (ALTERNATE FOR ACCEL TB) - Approved - Slight Effect OXIVIR TB - Approved - No Effect **OXYCIDE DAILY DISINFECTANT CLEANER - Approved - No Effect** PERISEPT 62 SPORICIDAL DISINFECTANT - Approved - No Effect PURELL FOOD SERVICE SANITIZER - Approved - No Effect SUPER SANI CLOTH GERMICIDAL WIPES (PURPLE LID) - Approved - Slight Effect SANI CLOTH HB GERMICIDAL WIPES (GREEN LID) - Approved - No Effect SANI-PROFESSIONAL MULTI SURFACE WIPES - Approved - Slight Effect SANI-PROFESSIONAL TABLE TURNERS WIPES - Approved - No Effect SANIZIDE PLUS SURFACE DISINFECTANT SPRAY - Approved - Slight Effect SIMPLE GREEN (1:10 DILUTION) - Approved - Slight Effect SANI CLOTH AF3 GERMICIDAL WIPES (GREY LID) - Approved - No Effect VIREX II 256- CONCENTRATE - Approved - No Effect VIROX AHP 5 DISINFECTANT CLEANER SURFACE WIPES - Approved - No Effect VIROX 5 CONCENTRATE (1:256 DILUTION; CN PRODUCT) - Approved - No Effect VIROX 5 RTU (CN PRODUCT) - Approved - Slight Effect ASEPTICARE TB-II - Not Approved - Severe Effect CAVICIDE - Not Approved - Severe Effect CLOROX BROAD SPECTRUM QUATERNARY DISINFECTANT CLEA... - Not Approved - Severe Effect SANI CLOTH PLUS GERMICIDAL WIPES (RED LID) - Not Approved - Severe Effect SANI CLOTH BLEACH GERMICIDAL WIPES (ORANGE LID) - Not Approved - Severe Effect WEX-CIDE 128 CLEANER - Not Approved - Severe Effect BLEACH (RATIO OF WATER TO BLEACH) See the bleach c ... - Approved - No Effect SUPER HDQ L 10 - Approved - No Effect OXIVIR FIVE 16 - Approved - No Effect OXIVIR TB WIPES - Approved - No Effect VIREX PLUS ONE-STEP DISINFECTANT CLEANER & DEODERI ... – Approved - No Effect EVACLEAN PURTABS 500ppm - Approved - No Effect SIMPLE GREEN TOWELS - Approved - No Effect MAXIM FACILITY + ONE-STEP DISINFECTANT CLEANER AND ... - Approved - No Effect 3M HB QUAT DISINFECTANT CLEANER CONCENTRATE 25L - Approved - No Effect OXIVIR 1 WIPES - Approved - No Effect

MAYERFABRICS

SPARTAN BNC-15 - Approved - No Effect

KEY	DEFINITION
Approved No Effect	No change in color or surface finish.
Approved Slight Effect	A change in color or surface finish only visible at certain angles.
Approved Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Not Approved Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the specimen.

The results for the cleaners/disinfectants listed does not imply "approved" or that the results are guaranteed. These evaluations are indicators after laboratory testing and may not be indicative of field performance. Customers should first determine if products are appropriate for use on their surfaces. The majority of today's disinfectant chemistries are mainly designed for use on hard environmental surfaces such as ceramic, porcelain, laminate, steel etc. After each application these types of disinfectants on seating surfaces the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue that could eventually discolor or degrade the material surface.

Failure to follow the above dilution recommendations, directions when using using these types of cleaners/disinfectants or the application of a clean water rinse after each application can expedite a product failure and will void any warranty claim.