

**MW | Coated****CLEANING CODE**

W: Water-Based Cleaner - Spot clean, using the foam only from a water-based cleaning agent, such as a mild detergent or non-solvent upholstery shampoo product. Apply foam with a soft brush in a circular motion. Always rinse promptly with clean water. Vacuum when dry. Pretest small area before proceeding.

CFC: Coated Fabrics Cleaning - When a spill/stain occurs wipe immediately with a clean dry cloth. Carefully remove the majority of the stain then follow the steps below.

Soap & Water - Remove ordinary dirt and smudges with a mild soap and water solution using a soft cloth or towel. Rinse with fresh water and wipe dry.

Non-abrasive Cleaners - If residue remains, use a straight application of the following cleaners: Fantastik or 409 and gently clean with a soft cloth. Rinse with fresh water and wipe dry.

Isopropyl Alcohol - More stubborn stains may be eliminated using a cotton cloth soaked in 70-91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft brush is recommended to clean valleys and crevices. Rinse with fresh water and wipe dry.

BC: Bleach Cleanable - 1 parts bleach, 4 parts water = 20% bleach, 80% water solution. Do not clean / disinfect fabric for longer than 10 minutes using the 20% bleach solution. Always rinse promptly with clean water after applying the bleach solution. Failure to do so will void any and all warranties.

Please note: If specific cleaners are not listed, then the pattern has not been tested for cleaning solution compatibility.

**DISINFECTANTS AND CLEANERS**

3M DISINFECTANT CLEANER RCT CONCENTRATE – Approved - Slight Effect

ASEPTICARE – Approved - No Effect

ASEPTICARE TB-II – Approved - No Effect

AVERT SPRACIDAL DISINFECTANT CLEANER – Approved - No Effect

AVISTAT-D RTU SPRAY DISINFECTANT CLEANER – Approved - No Effect  
BIREX SE DISINFECTANT – Approved - No Effect  
BLEACH (RATIO OF WATER TO BLEACH) See the bleach c... – Approved - No Effect  
BLEACH-RITE DISINFECTING SPRAY – Approved - No Effect  
CAVICIDE – Approved - No Effect  
CAVICIDE 1 – Approved - No Effect  
CAVIWIPES XL – Approved - No Effect  
CITRACE GERMACIDE – Approved - No Effect  
CLEAN ON THE GO HDQ C2 NEUTRAL DISINFECTANT – Approved - No Effect  
CLOROX BROAD SPECTRUM QUATERNARY DISINFECTANT CLEA... – Approved - No Effect  
CLOROX HEALTHCARE BLEACH GERMICIDAL CLEANER – Approved - No Effect  
CLOROX HEALTHCARE BLEACH GERMICIDAL WIPE – Approved - No Effect  
CLOROX HEALTHCARE EZ-KILL QUAT ALCOHOL CLEANER DIS... – Approved - No Effect  
CLOROX HEALTHCARE FUZION CLEANER DISINFECTANT – Approved - No Effect  
CLOROX HEALTHCARE HYDROGEN PEROXIDE CLEANER DISINF... – Approved - No Effect  
CLOROX HEALTHCARE VERSASURE CLEANER DISINFECTANT W... – Approved - No Effect  
CLOROX HYDROGEN PEROXIDE CLEANER DISINFECTANT SPRA... – Approved - No Effect  
CONCEPT 256N – Approved - No Effect  
DISPATCH HOSPITAL CLEANER DISINFECTANT WITH BLEACH – Approved - No Effect  
ERC PERFORMANCE WIPES – Approved - No Effect  
EVACLEAN PURTABS 500ppm – Approved - No Effect  
FADE-A-DYNE II – Approved - No Effect  
FANTASTIK ALL PURPOSE CLEANER – Approved - No Effect  
FORMULA 409 ALL PURPOSE CLEANER – Approved - No Effect  
FRESH BREEZE TB DETERGENTS – Approved - No Effect  
HALOMIST – Approved - No Effect  
HEPASTAT 256 – Approved - No Effect  
ISOPROPYL ALCOHOL – Approved - No Effect  
J-512 SANITIZER – Approved - No Effect  
KENNELSOL – Approved - No Effect  
LYSOL SPRAY DISINFECTANT – Approved - No Effect  
NLV-2 DISINFECTANT CLEANER & VIRUCIDE – Approved - No Effect  
OPTIM 33 TB DISINFECTANT (ALTERNATE FOR ACCEL TB) – Approved - No Effect  
OXIVIR 1 RTU – Approved - No Effect  
OXIVIR TB – Approved - No Effect  
OXIVIR TB WIPES – Approved - No Effect  
OXYCIDE DAILY DISINFECTANT CLEANER – Approved - No Effect  
PERISEPT 62 SPORICIDAL DISINFECTANT – Approved - No Effect  
ECOLAB PEROXIDE MULTI SURFACE CLEANER AND DISINFEC... – Approved - No Effect  
ECOLAB PEROXIDE MULTI SURFACE CLEANER AND DISINFEC... – Approved - No Effect  
POWER QUAT – Approved - No Effect  
PURELL HEALTHCARE SURFACE DISINFECTANT – Approved - No Effect  
PURELL MULTI SURFACE DISINFECTANT – Approved - No Effect  
REJUVENATE RTU WIPES ONE STEP – Approved - No Effect

RE-JUV-NAL – Approved - No Effect  
SANI CLOTH AF3 GERMICIDAL WIPES (GREY LID) – Approved - No Effect  
SANI CLOTH BLEACH GERMICIDAL WIPES (ORANGE LID) – Approved - No Effect  
SANI CLOTH HB GERMICIDAL WIPES (GREEN LID) – Approved - No Effect  
SANI CLOTH PLUS GERMICIDAL WIPES (RED LID) – Approved - No Effect  
SANI-24 GERMICIDAL SPRAY – Approved - No Effect  
SANI-HYPERCIDE GERMICIDAL SPRAY – Approved - No Effect  
SANI-PRIME GERMICIDAL SPRAY – Approved - No Effect  
SANI-PROFESSIONAL MULTI SURFACE WIPES – Approved - No Effect  
SANIZIDE PLUS SURFACE DISINFECTANT SPRAY – Approved - No Effect  
STERI-7 XTRA CONCENTRATE (recommended dilution rat... – Approved - No Effect  
STERI-7 XTRA WIPES – Approved - No Effect  
SUPER HDQ L 10 – Approved - No Effect  
SUPER SANI CLOTH GERMICIDAL WIPES (PURPLE LID) – Approved - No Effect  
TB-CIDE QUAT – Approved - No Effect  
VERT-2 GO ED – Approved - No Effect  
VIREX II 256- CONCENTRATE – Approved - No Effect  
VIREX PLUS ONE-STEP DISINFECTANT CLEANER & DEODERI... – Approved - Slight Effect  
VIROX 5 CONCENTRATE (1:256 DILUTION; CN PRODUCT) – Approved - No Effect  
VIROX 5 RTU (CN PRODUCT) – Approved - No Effect  
VIROX AHP 5 DISINFECTANT CLEANER SURFACE WIPES – Approved - No Effect  
VITAL OXIDE – Approved - No Effect  
WEX-CIDE 128 CLEANER – Approved - No Effect  
ALPHA HP MULTI-SURGACE DISINFECTANT – Approved - No Effect  
GENESAN'S CONTACT PLUS DISINFECTANT – Approved - No Effect  
3M HB QUAT DISINFECTANT CONCENTRATE – Approved - No Effect  
3M HB QUAT DISINFECTANT CLEANER CONCENTRATE 25L – Approved - No Effect  
CAVIWIPES HP – Approved - No Effect  
Array Quat-Clean – Approved - No Effect  
DIVERSEY ACCEL PREvention CONCENTRATE – Approved - No Effect  
ECOLAB DISINFECTANT 1 WIPE – Not Approved - Severe Effect  
SANI CLOTH PRIME GERMICIDAL WIPES (FUCHSIA LID) – Approved - No Effect  
LYSOL DISINFECTING WIPES – Approved - No Effect  
OXIVIR THREE 64 – Approved - No Effect

KEY	DEFINITION
Approved   No Effect	No change in color or surface finish.
Approved   Slight Effect	A change in color or surface finish only visible at certain angles.
Approved   Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Not Approved   Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the specimen.

The results for the cleaners/disinfectants listed does not imply "approved" or that the results are guaranteed. These evaluations are indicators after laboratory testing and may not be indicative of field performance. Customers should first determine if products are appropriate for use on their surfaces. The majority of today's disinfectant chemistries are mainly designed for use on hard environmental surfaces such as ceramic, porcelain, laminate, steel etc. After each application these types of disinfectants on seating surfaces the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue that could eventually discolor or degrade the material surface.

Failure to follow the above dilution recommendations, directions when using using these types of cleaners/disinfectants or the application of a clean water rinse after each application can expedite a product failure and will void any warranty claim.