MW | Coated



CLEANING CODE

W: Water-Based Cleaner - Spot clean, using the foam only from a water-based cleaning agent, such as a mild detergent or non-solvent upholstery shampoo product. Apply foam with a soft brush in a circular motion. Always rinse promptly with clean water. Vacuum when dry. Pretest small area before proceeding.

CFC: Coated Fabrics Cleaning - When a spill/stain occurs wipe immediately with a clean dry cloth. Carefully remove the majority of the stain then follow the steps below.

Soap & Water - Remove ordinary dirt and smudges with a mild soap and water solution using a soft cloth or towel. Rinse with fresh water and wipe dry.

Non-abrasive Cleaners - If residue remains, use a straight application of the following cleaners: Fantastik or 409 and gently clean with a soft cloth. Rinse with fresh water and wipe dry.

Isopropyl Alcohol - More stubborn stains may be eliminated using a cotton cloth soaked in 70-91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft brush is recommended to clean valleys and crevices. Rinse with fresh water and wipe dry.

BC: Bleach Cleanable - 1 parts bleach, 4 parts water = 20% bleach, 80% water solution. Do not clean / disinfect fabric for longer than 10 minutes using the 20% bleach solution. Always rinse promptly with clean water after applying the bleach solution. Failure to do so will void any and all warranties.

Please note: If specific cleaners are not listed, then the pattern has not been tested for cleaning solution compatibility.

DISINFECTANTS AND CLEANERS

3M DISINFECTANT CLEANER RCT CONCENTRATE – Approved - Slight Effect ASEPTICARE – Approved - No Effect ASEPTICARE TB-II – Approved - No Effect AVERT SPRACIDAL DISINFECTANT CLEANER – Approved - No Effect

500 S. KITLEY AVE., INDIANAPOLIS, IN 46219 TOLL FREE: 800.428.4415 T: 317.267.2626 F: 317-267-2629

MAYERFABRICS

AVISTAT-D RTU SPRAY DISINFECTANT CLEANER - Approved - No Effect BIREX SE DISINFECTANT – Approved - No Effect BLEACH (RATIO OF WATER TO BLEACH) See the bleach c ... - Approved - No Effect **BLEACH-RITE DISINFECTING SPRAY – Approved - No Effect** CAVICIDE - Approved - No Effect CAVICIDE 1 - Approved - No Effect CAVIWIPES XL - Approved - No Effect CITRACE GERMACIDE - Approved - No Effect CLEAN ON THE GO HDQ C2 NEUTRAL DISINFECTANT - Approved - No Effect CLOROX BROAD SPECTRUM QUATERNARY DISINFECTANT CLEA... - Approved - No Effect CLOROX HEALTHCARE BLEACH GERMICIDAL CLEANER - Approved - No Effect CLOROX HEALTHCARE BLEACH GERMICIDAL WIPE - Approved - No Effect CLOROX HEALTHCARE EZ-KILL QUAT ALCOHOL CLEANER DIS... - Approved - No Effect CLOROX HEALTHCARE FUZION CLEANER DISINFECTANT – Approved - No Effect CLOROX HEALTHCARE HYDROGEN PEROXIDE CLEANER DISINF ... - Approved - No Effect CLOROX HEALTHCARE VERSASURE CLEANER DISINFECTANT W ... - Approved - No Effect CLOROX HYDROGEN PEROXIDE CLEANER DISINFECTANT SPRA... – Approved - No Effect CONCEPT 256N - Approved - No Effect DISPATCH HOSPITAL CLEANER DISINFECTANT WITH BLEACH – Approved - No Effect ERC PERFORMANCE WIPES - Approved - No Effect EVACLEAN PURTABS 500ppm - Approved - No Effect FADE-A-DYNE II - Approved - No Effect FANTASTIK ALL PURPOSE CLEANER - Approved - No Effect FORMULA 409 ALL PURPOSE CLEANER - Approved - No Effect FRESH BREEZE TB DETERGENTS - Approved - No Effect HALOMIST - Approved - No Effect HEPASTAT 256 - Approved - No Effect ISOPROPYL ALCOHOL - Approved - No Effect J-512 SANITIZER - Approved - No Effect KENNELSOL - Approved - No Effect LYSOL SPRAY DISINFECTANT - Approved - No Effect NLV-2 DISINFECTANT CLEANER & VIRUCIDE - Approved - No Effect OPTIM 33 TB DISINFECTANT (ALTERNATE FOR ACCEL TB) - Approved - No Effect OXIVIR 1 RTU - Approved - No Effect OXIVIR TB - Approved - No Effect **OXIVIR TB WIPES – Approved - No Effect OXYCIDE DAILY DISINFECTANT CLEANER - Approved - No Effect** PERISEPT 62 SPORICIDAL DISINFECTANT - Approved - No Effect ECOLAB PEROXIDE MULTI SURFACE CLEANER AND DISINFEC ... - Approved - No Effect ECOLAB PEROXIDE MULTI SURFACE CLEANER AND DISINFEC ... – Approved - No Effect POWER QUAT - Approved - No Effect PURELL HEALTHCARE SURFACE DISINFECTANT - Approved - No Effect PURELL MULTI SURFACE DISINFECTANT - Approved - No Effect **REJUVENATE RTU WIPES ONE STEP – Approved - No Effect**

MAYERFABRICS

RE-JUV-NAL - Approved - No Effect SANI CLOTH AF3 GERMICIDAL WIPES (GREY LID) - Approved - No Effect SANI CLOTH BLEACH GERMICIDAL WIPES (ORANGE LID) - Approved - No Effect SANI CLOTH HB GERMICIDAL WIPES (GREEN LID) - Approved - No Effect SANI CLOTH PLUS GERMICIDAL WIPES (RED LID) - Approved - No Effect SANI-24 GERMICIDAL SPRAY - Approved - No Effect SANI-HYPERCIDE GERMICIDAL SPRAY - Approved - No Effect SANI-PRIME GERMICIDAL SPRAY - Approved - No Effect SANI-PROFESSIONAL MULTI SURFACE WIPES - Approved - No Effect SANIZIDE PLUS SURFACE DISINFECTANT SPRAY - Approved - No Effect STERI-7 XTRA CONCENTRATE (recommended dilution rat... – Approved - No Effect STERI-7 XTRA WIPES - Approved - No Effect SUPER HDQ L 10 - Approved - No Effect SUPER SANI CLOTH GERMICIDAL WIPES (PURPLE LID) - Approved - No Effect TB-CIDE QUAT - Approved - No Effect VERT-2 GO ED - Approved - No Effect VIREX II 256- CONCENTRATE - Approved - No Effect VIREX PLUS ONE-STEP DISINFECTANT CLEANER & DEODERI ... – Approved - Slight Effect VIROX 5 CONCENTRATE (1:256 DILUTION; CN PRODUCT) - Approved - No Effect VIROX 5 RTU (CN PRODUCT) - Approved - No Effect VIROX AHP 5 DISINFECTANT CLEANER SURFACE WIPES - Approved - No Effect VITAL OXIDE - Approved - No Effect WEX-CIDE 128 CLEANER - Approved - No Effect ALPHA HP MULTI-SURGACE DISINFECTANT - Approved - No Effect GENESAN'S CONTACT PLUS DISINFECTANT - Approved - No Effect 3M HB QUAT DISINFECTANT CONCENTRATE - Approved - No Effect 3M HB QUAT DISINFECTANT CLEANER CONCENTRATE 25L - Approved - No Effect CAVIWIPES HP - Approved - No Effect Array Quat-Clean – Approved - No Effect DIVERSEY ACCEL PREvention CONCENTRATE - Approved - No Effect ECOLAB DISINFECTANT 1 WIPE - Not Approved - Severe Effect SANI CLOTH PRIME GERMICIDAL WIPES (FUCHSIA LID) - Approved - No Effect LYSOL DISINFECTING WIPES - Approved - No Effect OXIVIR THREE 64 - Approved - No Effect

KEY	DEFINITION
Approved No Effect	No change in color or surface finish.
Approved Slight Effect	A change in color or surface finish only visible at certain angles.
Approved Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Not Approved Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the specimen.

The results for the cleaners/disinfectants listed does not imply "approved" or that the results are guaranteed. These evaluations are indicators after laboratory testing and may not be indicative of field performance. Customers should first determine if products are appropriate for use on their surfaces. The majority of today's disinfectant chemistries are mainly designed for use on hard environmental surfaces such as ceramic, porcelain, laminate, steel etc. After each application these types of disinfectants on seating surfaces the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue that could eventually discolor or degrade the material surface.

Failure to follow the above dilution recommendations, directions when using using these types of cleaners/disinfectants or the application of a clean water rinse after each application can expedite a product failure and will void any warranty claim.