

466 | Tekloom

CLEANING CODE

WS: Water/Solvent Cleaner - Spot clean with a mild solvent, an upholstery shampoo, or the foam from a mild detergent. When using a solvent or dry cleaning product, follow instructions carefully and clean only in a well-ventilated room. Avoid any product that contains carbon tetrachloride or other toxic materials. With either method, pretest a small area before proceeding. Always rinse promptly with clean water.

CFC: Coated Fabrics Cleaning - When a spill/stain occurs wipe immediately with a clean dry cloth. Carefully remove the majority of the stain then follow the steps below.

Soap & Water - Remove ordinary dirt and smudges with a mild soap and water solution using a soft cloth or towel. Rinse with fresh water and wipe dry.

Non-abrasive Cleaners - If residue remains, use a straight application of the following cleaners: Fantastik or 409 and gently clean with a soft cloth. Rinse with fresh water and wipe dry.

Isopropyl Alcohol - More stubborn stains may be eliminated using a cotton cloth soaked in 70-91% isopropyl (rubbing) alcohol. Wipe without spreading stain to surrounding area. A second application should be applied with vigorous rubbing in a circular motion. For highly textured material, a soft brush is recommended to clean valleys and crevices. Rinse with fresh water and wipe dry.

BC: Bleach Cleanable - 1 parts bleach, 9 parts water = 10% bleach, 90% water solution. Do not clean / disinfect fabric for longer than 10 minutes using the 10% bleach solution. Always rinse promptly with clean water after applying the bleach solution. Failure to do so will void any and all warranties.

Write-Away products from Mayer Fabrics defies unsightly ink spots and paint stains. Take action 'right away' on Write-Away products by following the cleaning instructions for Ink Stains. Always rinse thoroughly with clean water.

RECOMMENDED CARE AND CLEANING STEPS

General Maintenance:

While Tekloom® is inherently stain resistant, it is important to keep it clean at all times to maintain the original look and feel. Spot cleaning with a clean, soft towel with clean water will remove most of the everyday stains.

Disinfection:

This product can be disinfected with a 1:9 bleach dilution of water/bleach. Apply the solution using a misting spray bottle and gently scrub the affected area with a sponge or soft bristle brush. Allow the mixture to linger for the time specified by the Center for Disease Control and Prevention.

Avoid soaking the seamed area to prevent the bleach from penetrating through the protective layer.

Rinse all cleaning agents thoroughly with water and wipe with a soft cloth.

Residue left by cleaning agents will degrade and shorten the life and/or affect the product's appearance if not removed.

*Tekloom® protects the woven fabric with a patented, clear TPE layer. All approved cleaning chemicals should stay on the surface. Avoid soaking the seamed area to prevent the cleaning chemicals from entering the base fabric or the foam underneath.

DISINFECTANTS AND CLEANERS

- CAVIWIPES XL – Approved - No Effect
- CAVICIDE – Approved - No Effect
- CLOROX HEALTHCARE HYDROGEN PEROXIDE CLEANER DISINFECTANT WIPE – Approved - No Effect
- ECOLAB NEUTRAL DISINFECTANT CLEANER – Approved - No Effect
- FORMULA 409 ALL PURPOSE CLEANER – Approved - No Effect
- HYDROGEN PEROXIDE – Approved - No Effect
- LYSOL SPRAY DISINFECTANT – Approved - No Effect
- OXIVIR 1 RTU – Approved - No Effect
- OXIVIR FIVE 16 – Approved - No Effect
- OXIVIR TB WIPES – Approved - No Effect
- OXYCIDE DAILY DISINFECTANT CLEANER – Approved - No Effect
- PERISEPT 62 SPORICIDAL DISINFECTANT – Approved - No Effect
- STRIDE FRAGRANCE FREE NEUTRAL CLEANER (1:266 WATER) – Approved - No Effect
- SANI CLOTH AF3 GERMICIDAL WIPES (GREY LID) – Approved - No Effect
- VIREX II 256- CONCENTRATE – Approved - No Effect
- VIREX PLUS ONE-STEP DISINFECTANT CLEANER & DEODERIZER – Approved - No Effect
- WEX-CIDE 128 CLEANER – Approved - No Effect
- 3M C DIFF SOLUTION TABLETS – Approved - No Effect
- 3M NEUTRAL QUAT DISINFECTANT CLEANER CONCENTRATE 23H – Approved - No Effect
- 3M NEUTRAL QUAT DISINFECTANT CLEANER CONCENTRATE 23L – Approved - No Effect
- 3M HB QUAT DISINFECTANT CLEANER CONCENTRATE 25L – Approved - No Effect
- AMPHYL – Approved - No Effect
- ECOLAB A-456 II – Approved - No Effect
- STERIS (COVERAGE SPRAY HP PLUS) – Approved - No Effect
- OXIVIR PLUS – Approved - No Effect
- BLEACH (RATIO OF WATER TO BLEACH) See the bleach cleaning guide under Resources | Care and Maintenance – Approved - No Effect

KEY	DEFINITION
Approved No Effect	No change in color or surface finish.
Approved Slight Effect	A change in color or surface finish only visible at certain angles.
Approved Moderate Effect	A change in color or surface finish visible from all angles and directions, but does not appreciably alter the original condition of the material.
Not Approved Severe Effect	A change in color or surface finish, which obviously and markedly alters the original condition of the specimen.

The results for the cleaners/disinfectants listed does not imply "approved" or that the results are guaranteed. These evaluations are indicators after laboratory testing and may not be indicative of field performance. Customers should first determine if products are appropriate for use on their surfaces. The majority of today's disinfectant chemistries are mainly designed for use on hard environmental surfaces such as ceramic, porcelain, laminate, steel etc. After each application these types of disinfectants on seating surfaces the surface must be wiped with clean water and dried with a clean towel to remove any chemical residue that could eventually discolor or degrade the material surface.

Failure to follow the above dilution recommendations, directions when using using these types of cleaners/disinfectants or the application of a clean water rinse after each application can expedite a product failure and will void any warranty claim.